

| Cummins 6CT null | P/N |
|----------------------------|---------|
| Piston Kit | 3802398 |
| Piston Kit | 3802601 |
| Piston Kit | 3802657 |
| Piston | 3923164 |
| Piston | 3925878 |
| Piston | 3929161 |
| Piston Pin | 3934046 |
| Piston Ring Set | 3802429 |
| Retainer | 3920692 |
| Cylinder Liner Kit | 3802370 |
| Cylinder Liner | 3907792 |
| Cylinder Liner Seal Kit | 3802407 |
| Cylinder Liner | 3919937 |
| Cylinder Liner Seal Kit | 3907177 |
| Cylinder Liner Kit | 3800328 |
| Cylinder Liner | 3944344 |
| Liner Seal Kit | 3907177 |
| Main Bearing Set STD | 3945917 |
| Main Bearing Set 0.25mm OS | 3945918 |
| Main Bearing Set 0.50mm OS | 3945919 |
| Main Bearing Set 0.75mm OS | 3945920 |
| ConRod Bearing Set STD | 3901430 |

| | |
|------------------------------------|---------|
| Con Rod Bearing 0.25 OS | 3901431 |
| Con rod Bearing 0.50MM OS | 3901432 |
| Con Rod Bearing Set 0.75MM OS | 3901433 |
| Con Rod Bushing | 3943199 |
| Cam Shaft Bushing | 3943199 |
| Inlet Valve Kit With Lock | 3802463 |
| Valve Inlet Bare | 3924492 |
| Lock | 3901177 |
| Exhaust Valve Kit With Lock | 3802085 |
| Exhaust Bare Valve | 3921444 |
| Lock | 3901177 |
| Insert Valve Seat Inlet | 3924582 |
| Insert Exhasut Valve Seat | 3929005 |
| Guide Inlet And Exhaust Valve | 3923564 |
| Seal Inlet And Exhaust Valve Guide | 3927642 |
| Gasket Kit Upper | 3800750 |
| Gasket Kit Lower | 3800558 |
| Gasket Cylinder Head | 3938267 |
| Gasket Rocker Cover | 3905449 |
| Seal Kit Front | 4025270 |
| Seal Kit Front | 3901979 |
| Seal Kit Rear Dry | 3933262 |
| Seal Kit Rear Wet | 3909411 |

| | |
|-------------------------|---------|
| Thermostat Kit 83 Deg C | 3928639 |
| Water Pump ASSY | 3802081 |
| Water Pump ASSY | 3929612 |
| Oil Pump | 3800828 |
| Piston Cooling Nozzle | 3901020 |
| Piston Coolong Nozzle | 3905928 |
| Fuel Transfer Pump | 3930134 |
| Fuel Transfer Pump | 3936318 |